



SGV1

SG8V1

J4  
HEADER1X10

J5  
HEADER1X10

J1  
HEADER1X10

J2  
HEADER1X6

J3  
HEADER1X10

SPDATAI  
SPDATAO  
SPCLK  
SPCS

RESET  
SPDATAO  
SPDATAI  
SPCLK

+3V3

+3V3

+3V3

+3V3

+3V3

+3V3

+3V3

+3V3

5

4

3

2

1

D

D

C

C

B

B

A

A